

30

---

SUZUKI

## CONTENTS

**A**

APPLICATIONS

**B**

SPECIAL FUNCTIONS

**C**

REMOTE CONTROL PROGRAMMING

# APPLICATIONS

# A

VEHICLE	AIMODEL YEAR	CABLE
WAGON-R	ALL MODELS	ADC110-B-B
VITARA	ALL MODELS	ADC128
GRAND VITARA	ALL MODELS	ADC128
ALTO	ALL MODELS	ADC128
SWIFT	ALL MODELS	ADC128 Or ADC131-B
BALENO	ALL MODELS	ADC128 Or ADC131-B
IGNIS	ALL MODELS	ADC128
LIANA	ALL MODELS	ADC128
CARRY 1.3	ALL MODELS	ADC128
X-90	ALL MODELS	ADC128
SAMURAI	ALL MODELS	ADC128
JIMNY	ALL MODELS	ADC128
GRAND VITARA(SQ)	ALL MODELS	ADC128
GRAND VITARA(XL-7)	ALL MODELS	ADC128



# SPECIAL FUNCTIONS

# B

## KEY PROGRAMMING—ALL SYSTEMS

### DIAGNOSTIC MENU

ROVER  
SUBARU  
**SUZUKI**  
TOYOTA

Select **SUZUKI** and then select vehicle type.

**PRESS ENTER KEY**

PLEASE WAIT  
TRYING TO COMMUNICATE

### DIAGNOSTIC MENU

SYSTEM 1

Select **SPECIAL FUNCTIONS** from menu.

**PRESS ENTER KEY**

### DIAGNOSTIC MENU

ECU IDENTIFICATION  
FAULT CODES  
**SPECIAL FUNCTIONS**

Select **PROGRAM KEYS**

**PRESS ENTER KEY**

The tester will automatically enter the security pin code and program the key in the ignition.

### DIAGNOSTIC MENU

> **PROGRAM KEYS**

NOTE : If CODE ERROR is displayed then the access code is incorrect.

**PRESS ENTER KEY**

NOTE : Further keys can be added by repeating the above procedure by selecting PROGRAM KEYS.

# SPECIAL FUNCTIONS

# B

**PLEASE WAIT ..... 50**

The system will now count down from 50 to 0.

**SWITCH IGNITION OFF**

**DISCONNECT tester**

After it is completed switch ignition OFF and disconnect the tester

The key is now programmed.

For additional keys repeat the same procedure for more keys.

# SPECIAL FUNCTIONS

**B**

## KEY PROGRAMMING—WAGON-R ONLY

**DIAGNOSTIC MENU**

ECU IDENTIFICATION  
FAULT CODES  
**SPECIAL FUNCTIONS**

Select **SPECIAL FUNCTIONS** from menu.

**PRESS ENTER KEY**

**DIAGNOSTIC MENU**

> **PROGRAM KEYS**

Select **PROGRAM KEYS**

**PRESS ENTER KEY**



**SWITCH IGNITION OFF**

**PRESS ENTER**

The tester will automatically enter the security pin code.

NOTE : If CODE ERROR is displayed then the access code is incorrect.

.....

A series of dots will be displayed while the tester programs the key.

After the key is programmed the procedure complete screen will be displayed.

**PROCEDURE COMPLETE**

NOTE : Further keys can be added by repeating the above procedure by selecting PROGRAM KEYS.

## **VITARA**

### *Procedure*

1. Switch ignition OFF and close all doors.
2. Open drivers door and switch ignition on
3. Switch ignition OFF
4. Press and release drivers door ajar switch 3 times
5. Switch ignition ON and then OFF
6. Press and hold each button of the remote in turn for 5 seconds each
7. Central locking should activate
8. Press remote control lock button
9. Maximum of 2 remotes possible

## **SWIFT RS 413 and RS 415**

If transmitter or BCM (included in junction block assembly) is replaced with a new one or additional transmitter(s) is necessary, program transmitter code(s).

### *Procedure*

- 1) Confirm that all doors are closed and ignition key is out of ignition key cylinder
- 2) Open driver side door.
- 3) Turn ignition switch to ON position, and then remove ignition key from ignition key cylinder within 10 seconds after that.
- 4) Push and release driver side door switch (1) at 3 times by hand within 20 seconds after removing ignition key from ignition key cylinder.
- 5) Turn ignition switch to ON position, and then drawn ignition key from ignition key cylinder within 10 seconds after that. All doors automatically lock and unlock once. With this, registration mode.
- 6) Push "UNLOCK" button (2) on transmitter (3) within 20 seconds after Step 5. All doors automatically lock and unlock once. With this, code registration is completed.
- 7) If an additional transmitter, needs to be programmed repeat the procedure of Step 1.